



File Name: bp 250 ericsson manual.pdf

Size: 2465 KB

Type: PDF, ePub, eBook

Category: Book

Uploaded: 27 May 2019, 17:40 PM

Rating: 4.6/5 from 771 votes.

Status: AVAILABLE

Last checked: 4 Minutes ago!

In order to read or download bp 250 ericsson manual ebook, you need to create a FREE account.

[**Download Now!**](#)

eBook includes PDF, ePub and Kindle version

[Register a free 1 month Trial Account.](#)

[Download as many books as you like \(Personal use\)](#)

[Cancel the membership at any time if not satisfied.](#)

[Join Over 80000 Happy Readers](#)

Book Descriptions:

We have made it easy for you to find a PDF Ebooks without any digging. And by having access to our ebooks online or by storing it on your computer, you have convenient answers with bp 250 ericsson manual . To get started finding bp 250 ericsson manual , you are right to find our website which has a comprehensive collection of manuals listed.

Our library is the biggest of these that have literally hundreds of thousands of different products represented.



Book Descriptions:

bp 250 ericsson manual

Loudspeaker Handset with hearing aid function Please note The handset may retain small metal objects in the earcap region.You are connected to the first caller.Press to redial the last dialled external number The display will show the dialled number.Press to park the first call Inquiry or Line 2 Second call is connected.Your telephone will ring again.Press the line key Line 1 The lamp flashes slowly.Cancel internal diversion Press Press Diversion Individual diversion is cancelled.A special dial tone reminds you that "Call forwarding" is active. The display shows that you have activated an external diversion.Dial Dial your number Press Dial tone.If a message arrives, the lamp starts flashing, see section "Check and store received messages".External callers will be routed to the operator who also has access to your absent info.See section "Security".COMMON MAILBOX SYSTEM Callers are able to leave messages in the common mailbox. Activate Divert your extension to the mailbox system.Press to finish programming Cancel one specific individual abbreviated number Press Enter an abbreviated number between 0 and 9 and press Cancel all individual abbreviated numbers Press Confirmation tone.Dial The system shows the accumulated costs since the last reset.Call a groupmember Michael Press to make the calls directly preprogrammed Note If the key is flashing, you will automatically pickup your colleague's ongoing call.Please ask your system administrator for the configured number.Note You can also program the common bell code on a function key.Press to cancel the music Note You can adjust the volume, see section "Audible adjustments".Note To accept a transferred external call you must first press the Transfer key.Note If you program a new diversion address, remember to re set it when you return to your office.Night Press to activate or deactivate preprogrammed When the lamp lights, night switch is active. When the lights extinguishes, night switch is passive.<http://www.crigroups.com/home/content/45/11775545/html/admin/uploadsxxx/dometic-fridge-manuals.xml>

- **ericsson bp 250 manual, ericsson bp 250 installation manual, bp 250 ericsson manual, bp 250 ericsson manual download, bp 250 ericsson manual pdf, bp 250 ericsson manual 2017, bp 250 ericsson manual 2016.**

Dial Dial your password and press Dial your extension number and press Dial tone. You can make one call from the blocked extension.Dial the digits for external call access and the external number Note You can also program the LCR code on a function key.MCID REJECTED DISPLAY REST After 3 seconds the display will return to the previous display.If you want to leave the function before the timeout, press the "Clear"key.Note If you do not react within 5 seconds the display is returned to idle state. If you want to leave the function before the timeout, press the "Clear"key.When a recording of the telephone conversation is needed, TAPE RECORDER for evidence purposes, a tape recorder can be connected.Put the name referring to the programmed function in the field above the line to indicate that it is the primary function.Muted signal. Note Accessible functions, depends on the programming of the system.Slowly flashing lamp The line or function is put on hold. Rapidly flashing lamp An incoming call or message waiting. Light with short breaks Ongoing call.HANDSET AND LOUDSPEAKER Use the volume keys. You can set different volume. You only have to press the last digit to select another ringing character.Scroll within the melody Press to move the cursor within the melody Hold the key to move to the beginning or the end.How to exit melody mode, see section "Melody mode".See section "Other useful facilities". To intrude on an ongoing call when a requested extension is busy.You can set your own password. See section "Security". Public Branch Exchange. Your telephone switching system e.g. BusinessPhone 250. PREDEFINED TEXT

Preprogrammed absent information. See section "Information". Change cables To remove a cable, push down the plug's stop. Use a screwdriver to unlock the stop. Any damages of the telephone, that are caused by nonobservance of these instructions, are not part of the liability given by the manufacturer. <http://xn--42-6kcdlkbomh7beggito5p.xn--p1ai/userfiles/dometic-fridge-freezer-manual.xml>

You can restrict connections between the external lines by reprogramming your system. Please ask your system administrator or contact our service center for more information. Ericsson provides total solutions covering everything from systems and applications to mobile phones and other communications tools. With more than 100,000 employees in 140 countries, Ericsson simplifies communications for customers all over the world. It is a state-of-the-art business communications system. Its alliance of features and facilities effectively improves communications for virtually any kind of organization. See section "During calls". Clear To disconnect calls. Loudspeaker Handset with hearing aid function Please note The handset may retain small metal objects in the earcap region. BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. Lift the handset to receive the new call BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. You can monitor calls, mute the microphones, make an inquiry, transfer the call, create a conference or put the call on hold to perform other tasks. Press to park the second call Line First call is connected. Press to park the first call Inquiry Second call is connected. Press to end the ongoing call BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. Your telephone will ring again. BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. Press the line key Line The lamp flashes slowly. Press again to retake the parked call Line Note This is also valid for the "inquiry" key. BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. A special dial tone reminds you that "Call forwarding" is active. Cancel diversion Dial Press BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone.

If a message arrives, the lamp starts flashing, see section "receive message". External callers will be routed to the operator who also has access to your absent info. continued BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. Note You can dial your own extension number if you want to check your information. BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. Information is active. Press to finish the procedure BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. See section "Security". Press to finish the procedure BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. Press Press to finish the procedure When the diversion to your mailbox is activated, the Diversion lamp shows steady light. Deactivate Press Press to finish the procedure BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. See section "Security". BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. How to enter information, see section "Enter information". 2 Activate diversion to the mailbox system How to activate, see sections "Individual mailbox system" or "Common mailbox system". BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. Lift the handset Michael P. Press to make a call preprogrammed BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. Lift the handset and press Dial the abbreviated number A number between 0 and 9. continued BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. Lift the handset Paging Press preprogrammed An internal call is established with the paging party. BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone.

Call a group member Lift the handset Michael Press to make the calls directly preprogrammed Note

If the key is flashing, you will automatically pickup your colleague's ongoing call. BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. Please ask your system administrator for the configured number. Lift the handset Dial the group call pickup code BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. Note You can also program the common bell code on a function key. BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. Cancel reminder Press to cancel all settings Press to finish the procedure BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. Account number Press preprogrammed Enter account number and press BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. Night Press to activate or deactivate preprogrammed When the lamp lights, night switch is active. When the lights extinguishes, night switch is passive. BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. Which code to use and how to change it, see section "Select Personal Code". See last page for a card to remember these specific numbers. BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. Note You can also program the dooropener's directory number as a common abbreviated number or a function key. BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. Dial your new code and press Verification tone. Press to finish the procedure BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. You can make one call from the blocked extension. BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. Dial the digits for external calls and external number Note You can also program the LCR code on a function key. BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone.

TAPE RECORDER When a recording of the telephone conversation is needed, for evidence purposes, a tape recorder can be connected. BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. Note Special authorisation is required when programming functionkeys. BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. Slowly flashing lamp The line or function is put on hold. Light with short breaks Ongoing call. BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. Press to finish the procedure Note When type 2 is selected, the programming of the ringing volume is not applicable. BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. You only have to press the last digit to select another ringing character. Press to finish the procedure BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. See section "Other useful facilities". **INTRUSION** To intrude on an ongoing call when a requested extension is busy. See section "Outgoing calls". continued BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. See section "Other useful facilities". Your telephone switching system e.g. BusinessPhone 250. **PERSONAL CODE** A fourdigit code needed to e.g. block your extension and retrieve messages from the mailbox system. Change cables To remove a cable, push down the plug's stop. Use a screwdriver to unlock the stop. BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. Any damages of the telephone, that are caused by non observance of these instructions, are not part of the liability given by the manufacturer. BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. You can restrict connections between the external lines by reprogramming your system.

Please ask your system administrator or contact our service center for more information. BusinessPhone 250 Basic Telephone BusinessPhone 50 Basic Telephone. Their combined expertise in fixed and mobile networks, mobile phones and infocom systems makes Ericsson a worldleading supplier in tele communications. Please enable JavaScript in your web browser. Unlike other phone systems in its class, BusinessPhone has been specifically created to meet the needs of small to medium sized organizations, with anything from just a few up to 200 extensions. It caters for organisations requiring between 20 and 200 extensions at a single location. All system hardware and software in the BusinessPhone solution is modular. This makes it adaptable to a wide range of

capacity and functional requirements, and provides the capability for further system expansion and feature enhancement at any time. Features like PBX networking, ISDN connectivity to the desktop, integrated cordless extensions and voice messaging, computertelephony integration CTI and complete call center capability. Two line keys, with freeonsecond access, help ensure that important calls are not missed The phone may also be used to program some of the system configurations, such as PBX or key system configurations and comes with builtin handsfre function. Up to two additional key panels, each with 17 programmable keys, can be attached to the phone to provide a total of up to 48 dualpurpose keys. The additional hardware and software modules are fully integrated into the BusinessPhone central unit. All manuals on ManualsCat.com can be viewed completely free of charge. By using the Select a language button, you can choose the language of the manual you want to view. Standard and Economyplus Telephone. System telephone for. BusinessPhone 250 and BusinessPhone 50Welcome to the User Guide for the Standard and EconomyplusIt is a stateofheart business communications system.

Its alliance ofTo take full advantage of these advanced featuresOn the StandardNote The features described in this user guide areBusinessPhone 50 system. Some might not work inThe User Guide describes the facilities of the BusinessPhone systemNote Dialog 3211 and 3212 are system telephones, i.e.Function descriptions that do not include speaking in the handThe dualfunctions keys allow two functions to be combined onExample to access the Information function. Press the key 2ndAnswer Lift handset or Line1. Answer on anotherMake calls. Internal calls Ext. No. External calls 0 External No. CommonIndividualLast external. Save externalYou get busy tone or no answer. Automatic callback 5 Replace handset. Lift handset when called back. Camp on 4 Keep handset off hook. Intrusion 8. Conference. OngoingInquiry. OngoingRefer back Line1 or Line2End call. Transfer. Transfer a call Inquiry Call 3rd party. Transfer or. Replace handsetDuring calls. Switch to handsfree Replace handset. Switch to handset Lift handset. Group listening. Individual hold Line1. Press flashing key to retake. Tandem configuration. Transfer a callTransfer. Quick Reference Guide and Quick Reference Card. Standard and Economyplus Telephone. System telephone for BusinessPhone 250 and BusinessPhone 50. Password. DISA and Message check. Company number. DISA Number Message systemThisProject name Account number. Special account numbers for business callsFixed diversion 2nd Diversion. Internal diversion 2nd. Diversion New No.Cancel internalFollow me, redirectCancel fromBypass call. External diversion. Reminder. Messages. Voice Message 9 Speak. Rerecord 9 Speak. Check received Message. Information. Enter informationEnter "Info code" and. Info code Completing info. Time of return 1. hour 0023 minute 0059. Date of return 2. month 0112 day 0131. Lunch 3. back at, hour minute. Meeting 4. back at, hour minute. Vacation 5. back, month day. Illness 6. back, month day.

Individual abbreviated numbersTable of ContentsDescription.6. Incoming Calls.8. Outgoing Calls.11. During Calls.14. Call Forwarding.19. Information.26. Internal Messages.31. Mailbox System.35. Abbreviated Numbers.39. Call Metering.43. Group Facilities.45. Other Useful Facilities.50. Security.57. Least Cost Routing.60. ISDN Facilities.61. Optional Equipment.67. Programming.71. Display Info.75. Visible Signals.77. Audible Adjustments.78. Tones and Signals.83. Glossary.85. Installation.88. Useful Hints.91. Index.92. Designation Card Manager and Voice Guide.97. All rights reserved. No parts of this publication may be reproduced,Note The graphic above is valid for the Standard as wellThe EconomyplusKey for access to secondary key functions These functions areDescriptionMessage. Info. Diversion. Inquiry. Line 2. Line 1See section "Internal messages".Storing numbers, program functions. See section "Programming".The headset key is programmed bySee section "Optional equipment".See section "During calls". See section "Call forwarding".See section "During calls".See sectionSee section "Outgoing calls".To adjust the volume. See section "Audible Adjustments".To switch the microphone on or off. See section "During calls". To switch the loudspeaker on or off. See section "During calls".To disconnect calls or to clear the display in programming.Please note The handset may retain small metalIncoming Calls. Internal

calls. A ringing signal and a flashing lamp indicates an incoming call. The display shows the number and the name of the internal caller. External calls. If you are connected to a digital trunk line ISDN, the display shows the number of the trunk line. A trunk line is the same as an external line. Answer calls. Lift the handset. Handsfree. Line 1 Press without lifting handset. You are connected to the caller via the loudspeaker and microphone. Press to terminate a handsfree call. On another extension.

You can answer a call to another extension from any phone in the system. Call the ringing extension. You receive busy tone. Allow calls on line 2. If you want to receive calls also while speaking you first need to see section "Programming". When Free on 2nd access is active the lamp lights and you can answer a second call. You are on the phone, when a muted ringing signal and a line key flash. Line 2 Press the flashing line key. The first call is parked. To switch back to the first call. Line 1 Press the first line key. The second call is parked. You are connected to the first caller. Press if you want to terminate the ongoing call. Silent ringing. This function is useful if you do not want to be disturbed by the standard telephone. Incoming calls will only be indicated on the display and by the flashing line key. Note This function requires a certain release number. In idle mode. Press to mute the ringer for incoming calls. Outgoing Calls. Sometimes you make a call but the person is not available. These functions will help you in your attempts to establish a call. Make calls. How to make internal and external calls. Lift the handset and dial either. An extension number to make an internal call. Note Which digit to press for external call access. Note You can make your calls faster, using common handsfree. Without lifting the handset, just press a line key, or the flashing line key. The call is in progress. Last external number redial. When you initiate an external call the system automatically redials the number. The display will show the dialled number. Save external number. When you make an external call, you can save the number in the memory. Previously saved number is erased. Save number. Before you quit the call. Redial number. Automatic callback. You call an extension and receive busy tone or get no answer. Verification tone. You are called back if the extension finishes the ongoing call or the extension is busy. You have to answer. Lift the handset when you are called back. Busy extension.

You call an extension and receive busy tone. Campon. You can notify a busy extension of your call by a muted ringing signal. Keep the handset off hook. When the called extension replaces the handset, the busy tone again, the desired extension is reached. Intrusion. You can intrude on an ongoing call on a busy extension. Intrusion tone is heard and a three-party call is established. When the called extension replaces the handset and you keep off hook, the busy tone is heard. Note If you still hear the busy tone, then your extension is busy. During Calls. The BusinessPhone 250 and BusinessPhone 50 system allows you to switch between group listening. You have an ongoing conversation via the handset. Press to switch the loudspeaker on or off. When the lamp lights, the loudspeaker monitors the call. Note You can adjust the volume, see section "Audible". From handset to handsfree. Press to switch the loudspeaker on. You are now in the group listening mode. Replace the handset. Handsfree conversation. Note You can adjust the volume, see section "Audible". Press to end the call. From handsfree to handset. You have an ongoing handsfree conversation. Conversation via the handset. Mute. You have an ongoing conversation. Press to switch the microphone on or off. When the lamp lights, the caller will not be able to hear the handset. Inquiry. During an ongoing conversation you like to make an inquiry to another extension. Inquiry Press. The first call is put on hold the lamp flashes slowly. Call the third party. When the third party answers you can switch between the calls. End inquiry. Press to end the inquiry call. The second call is disconnected. Line Press to retake the first call. Now you are connected to the first party. Refer back. You have an ongoing conversation on e.g. Line 2 and want to switch to Line 1. Line 1 Press to park the second call. First call is connected. Second call is connected. Press to end the ongoing call. You have an ongoing internal or external conversation and you want to transfer the call. Inquiry Press. You can transfer the call before answer or wait for answer.

Note Make sure, that you are connected to the desired extension. Transfer Press. Replace the handset. The call is transferred. External calls might only be transferred to a busy extension. You can even

transfer calls to busy extensions. The other partyCallback. You are called back, if you have transferred an external call andConference. You have an ongoing conversation and you want to establish aInquiry Press. Call the third partyConference Press to establish a three party conference. Now you have established a three party conference. To mark theRepeat the procedure to include other persons to theIn this way, you can include up to six parties in a conversation. How many of them can be external callers depends on theIndividual hold. You have an ongoing conversation, i.e. the "Line 1"key is lit. Now you want to park the ongoing call for a short while. Line 1 Press the line key. The lamp flashes slowly. Line 1 Press again to retake the parked call. Common hold. Hold Press preprogrammed. The line key lamp flashes slowly. The call can be picked up onLine 1 Press to pick up on own extensionPick up on another extension. Call the extension that put the call on holdCall Forwarding. When you are not available to take calls or decide to answer yourIf you urgently need to talk to someone who has forwarded hisDepending on the type of diversion you are also able to recordNote You can still make calls as usual. Diversion on no reply. If you are not available to answer incoming calls internal orDiversion on busy. If your extension is busy and you receive an incoming callFixed diversion. This function directs your calls to a preprogrammed answeringActivate fixed diversionDiversion Press to activate diversion. All calls to your extension are directed to a preprogrammedCancel diversionDiversion Press to cancel diversionProgram fixed diversion address. If you need to program a new diversion addressDiversion Press. Dial new diversion addressDiversion Press.

Press to finish the procedureIndividual diversion. This feature gives you the possibility to divert your calls to internalNote In order to prevent misuse, individual externalProgram and activate internal diversion. Divert your calls to an internal position.Diversion Press and dial the new directory number. Any directory number.Diversion Press. Verification tone. The diversion lamp lights and remains lit. The display shows the actual follow me state. Press to finish the procedure. You can make outgoing calls as usual. A special dial toneNote An individual internal diversion cannot be activatedCancel internal diversionDiversion Press. Individual diversion is cancelled. The lamp extinguishes.Program and activate a new external diversion address. To set a new individual external diversion addressA maximum of 24 digits. Verification tone. Note Individual external diversion can also be used viaCancel external diversion. Press. Note The programmed diversion address is notReactivate external diversion. Divert your calls to an external position. A special dial toneThe display showsPressFollow me. If you are in another room, you can still answer your calls byTo activate Follow me,Activate follow me. Note This procedure has to be executed from theSpecial dial tone. Cancel follow me. Follow me and individual diversion can also be cancelled from theDial your number. Dial tone. Press to finish the procedureBypass call forwarding. Bypass call forwarding makes it possible to call a specificEnter extension number. You will be connected to the specified extension, regardless ofInformation. If you are not in the office for a certain period of time e.g. meetExternal callers will be routed to theNote When you have activated a diversion with aYou can inform your callers withEnter the reason for your absence and the date and time of yourRecord a voice message and name your absent information. Enter information. To store text or voice information.

Info PressSelect "Predefined text" or "Voice information"Predefined texts. Enter "Code" and. Enter "Completing info" from the table below. Code Completing info. Time of return 1 hour 0023 minute 0059. Date of return 2 month 0112 day 0131. Lunch 3 back at, hour minute. Meeting 4 back at, hour minute. Vacation 5 back, month day. Illness 6 back, month day. The programmed absence info will be shown in the display. Internal callers receive the information on the display or as spokenExternal callers will bePredefined texts example. Vacation, back June 27Info PressInformation active.Voice informationInfo PressPress to finish the procedure.